

# VALENITE E-Z SET TO RIGIBORE CONVERSIONS – INCH

(OF THE MORE POPULAR STYLES)

**NOTE – Valenite codes specify a bushing code PLUS a cartridge (nib) code depending on the style/type of insert required. Rigibore specifies the whole unit assembly code.**

This list does not attempt to be exhaustive but represents a cross-over for styles most commonly asked about. If you have a style not listed we would be happy to identify and offer our nearest equivalent.

Valenite Bushing	Cartridge	Hole	Approach	Rigibore Unit (Approach)
<b>BUAA</b>	AHAC-3	A-Ang	93°	BTR2B2 (90°)
	ASACS		85°	BTR2B2L (75°)
<b>BUAV</b>	AHVCS	A-Vert.	90°	BTR2B5 (90°)
	ASVCS		85°	BTR2B5L (75°)
<b>BUBA</b>	BHAC-3	B-Ang	93°	BTR3B1–BTR3B2 (90°)
	BSACS		85°	BTR3B2L (75°)
<b>BUBV</b>	BHVCS	B-Vert.	90°	BTR3B5 (90°)
	BSVCS		85°	BTR3B5L (75°)
<b>BUCA</b>	CHAC-3	C-Ang	93°	BTR5B2 (90°) BTR5B2L (75°)
	CHA-10		90°	
	CSACS		85°	
<b>BUCV</b>	CHVCS	C-Vert.	90°	BTR5B5 (90°)
	CLVC-1		90°	
	CSVCS		85°	
	CLVC-2		75°	BTR5B5L (75°)
<b>BUEA</b>	EHAC-3	E-Ang	93°	BTR7B2 (90°) BTR7B2L (75°)
	EHA-10		90°	
	ESACS		85°	
<b>BUEV</b>	EHVCS	E-Vert.	90°	BTR7B5 (90°)
	EHV-10		90°	
	ESVCS		85°	
	ELV-20		75°	BTR7B5L (75°)
<b>BUGA</b>	GHAC-3	G-Ang	93°	BTR10B2 (90°) BTR10B2L (75°)
	GHA-10		90°	
	GSACS		85°	
<b>BUGV</b>	GHVCS	G-Vert.	90°	BTR10B5 (90°)
	GLVC-1		90°	
	GLV-10		90°	
	GLV-20		75°	BTR10B5L (75°)

**Codes starting BU = Basic unit, then the size ie. A, B,C,E & G. Then Angular or Vertical mount A or V.**

**So a BUAA = Basic unit, size A, angular mounted.**

**Cartridge (nib) codes will start with size letter then various codes for insert/style variations.**

**Note:** These are not a direct equivalent to valenite units, there could be slight differences in cutting edge positions. Bar may also require drilling for hexagon wrench access to clamping screw, please check dimensions before ordering.